

Universal Hitch Helper installation procedures.

Hardware List

3- Screw, #8 x 3/4" Black

1. Start your installation by cleaning the pin box with a clean cloth. (fig.1)
2. Position the Universal Hitch Helper pod on the pin box. (fig.2)
3. Finally, take the three #8 self tapping screws and screw the pod to the pin box.(fig.3-4)

