

# INSTALLATION INSTRUCTIONS

## Soft Touch Assist Handle

AH-100, AH-150



### Soft Touch Assist Handle

Models: AH-100 White  
AH-150 Black



1. Place the Soft Touch rail at your desired mounting location.
2. The rail's mounting holes are offset, so you can mount the rail to your coach's door frame. This rail will only support its user as well as it is attached to the coach – **be sure you secure it to the door frame or a stud in the wall of your coach.**
3. Mark the four screw holes.
4. Drill 1/8" pilot holes.
5. Place waterproof caulk in the holes to prevent moisture from entering your coach's wall.
6. Prior to the caulk setting up, mount your Soft Touch rail using the provided fasteners.

### Contents

- (1) Soft Touch Assist Rail
- (4) 2-1/4" x #18 Stainless Steel Fasteners

INS-2625 10.29.2020